

Using Date/Time Records

You can use the procedure in this section to create a date/time record of the current date (month, day, year) and time (minute second). You can later recall a record to view it.

Important!

- The watch has memory for storage of up to 40 records of various types. If you perform an operation that creates a new record while there are already 40 records in memory, the oldest record is deleted automatically to make room for the new one (page E-70).
1. In the Timekeeping Mode, hold down **(C)** until the watch beeps (about 0.5 seconds).
 - **REC** will appear on the display, indicating that a record of the current date and time was created. After about one second, the watch will return to the Timekeeping Mode screen.
 2. To view a record, enter the Data Recall Mode (page E-26) and use the **(A)** and **(C)** buttons to scroll. See “Viewing Memory Records” (page E-70) for more information.